



MANUAL EN

DVC04C




EXTRA WIRELESS DOOR CHIME ACCESSORY IP VIDEO DOORBELL DVC040IP

Home is not a place, it's a feeling


EN MANUAL - Extra wireless door chime

Accessory video doorbell DCV040IP


1. INSERTING BATTREIES



2. LINKING TO VIDEO DOORBELL DVC040IP



3. RESETTING



Turn the switch to ON while pressing the reset button.

SPECIFICATIONS DVC04C

| | |
|---------------------|------------------------|
| Batteries | : 3 x 1,5V DC; AA type |
| Standby current | : Max. 0,25 mA |
| Working current | : Max. 0,75 mA |
| Volume | : Max. 85dB |
| Wireless frequency | : 433,92 MHz |
| Open range distance | : ca. 80 m |
| Dimensions | : 85 x 85 x 26 mm |
| Melodies | : 8 |

IMPORTANT WARNING:

This package can contain small parts and/or materials which can be dangerous to small children!
Be aware of this, and keep this away from small children!

Symbols:

Recycling and disposal: The WEEE symbol (a) means that this product and batteries must be disposed separately from other household waste. When it reaches its end of life, take it to a designated waste collection point in your area to guarantee a safe disposal or recycling. Protect the environment, human health and natural resources! Read the manual (b) before use and store it in a safe place for future use and maintenance.

